


KINGSLEY-BATE

Fine Garden Furniture

ASSEMBLY INSTRUCTIONS FOR THE CL-15/20/38/45




LEG ASSEMBLY



TOP



LEG ASSEMBLY



NOTE:

A TENON

B MORTISE HOLE

STEP-I

Unpack, inspect and lay the parts on a clean, flat, soft surface to avoid marring the wood.

NOTE: During assembly of the furniture please match all joints with the corresponding letters or numbers stamped on the furniture.



STEP-II

Fit the LEG ASSEMBLY mortise holes to the TOP tenons. If necessary, gently rock the LEG ASSEMBLY while pushing tenons into mortise holes until joints fit snugly. Make sure to match the numbered tenons with the corresponding mortise holes.



STEP-III

Carefully hammer the dowels into the pre-drilled holes of the assembly, details are shown in the photographs. **NOTE: DO NOT FORCE THE DOWELS; ANY EXCESS CAN EASILY BE SANDED AWAY. IF THE DOWELS ARE NOT FLUSH DO NOT CONTINUE TO DRIVE THE DOWELS, YOU MIGHT DAMAGE THE ITEM.**



STEP-IV

Secure the aprons of the LEG ASSEMBLIES to the underside of the TOP with the screws provided (see photo). Please use a proper screw driver, use of a power screw driver or drill with screw driver bit could damage the furniture.

IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY-BATE FURNITURE, PLEASE CONTACT THE KINGSLEY-BATE DEALER NEAREST TO YOU OR KINGSLEY-BATE DIRECTLY. WE THANK YOU FOR CHOOSING OUR FURNITURE.

**KINGSLEY-BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.*