


KINGSLEY BATE

Fine Garden Furniture


ASSEMBLY INSTRUCTIONS FOR THE GV-55



RIGHT END FRAME




INSERTS



LEFT END FRAME




BACKS SLATS




SEAT FRAME



MIDDLE LEG



HARDWARE



*** NOTE**



A TENON

B MORTISE HOLE

STEP-I

Unpack, inspect and lay the parts on a clean, flat, soft surface to avoid marring the wood.

NOTE: During assembly of the furniture please match joints with the corresponding letters or numbers stamped on the wood.





STEP-II

Fit the MIDDLE LEG onto the SEAT FRAME, secure the MIDDLE LEG and SEAT FRAME with the bolt and Allen key provided and carefully set off to the side. Gently lay the END FRAME with the stamps near the mortise holes on a clean, flat surface and fit the BACK SLATS into the END FRAME mortise holes as shown in the above photographs. Carefully line up and fit the BACK SLATS into the MIDDLE LEG holes while adding the SEAT assembly to the END FRAME (we recommend a second person help with this step). If necessary, gently rock the parts while pushing down on them until all the joints fit snugly together.



STEP-III

Carefully fit the rest of the BACK SLATS into the MIDDLE LEG mortise holes and fit the remaining END FRAME mortise holes over all exposed tenons. Using a rubber mallet or a regular hammer with the sanding block between the hammer and the wood, gently drive all the mortise holes onto the tenons until all joints fit snugly together.



STEP-IV

Carefully hammer the proper dowels into the pre-drilled holes of the assembly small dowels “S “ for the back , “M” for the front seat and long dowels “L” for the back seat and the slats near the seat, details are shown in the photographs and all dowels (and/or dowel bags) are marked to match where they go. You will need 2 people to upright the Settee. **DO NOT TIP OVER.** To upright lift off the ground, rotate to horizontal position and set item down. Drop SEAT INSERTS into place.

NOTE: DO NOT FORCE THE DOWELS; ANY EXCESS CAN EASILY BE SANDED AWAY. IF THE DOWELS ARE NOT FLUSH DO NOT CONTINUE TO DRIVE THE DOWELS, YOU MIGHT DAMAGE THE ITEM.

IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY BATE FURNITURE, PLEASE CONTACT KINGSLEY BATE CUSTOMER SERVICE AT 703-361-7000. WE THANK YOU FOR CHOOSING OUR FURNITURE.

** KINGSLEY BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY**

7200 Gateway Court, Manassas, Virginia 20109
Phone: 703-361-7000, Fax: 703-361-7001