KINGSLEY BATE

Fine Garden Furniture
ASSEMBLY INSTRUCTIONS FOR THE HY-118










TABLE TOP



LEG ASSEMBLY







* NOTE A TENON B MORTISE HOLE

HARDWARE

DOWEL

STEP-I

Unpack, inspect and lay the parts on a clean, flat, soft surface to avoid marring the wood.

NOTE: During assembly of the furniture please match all joints with the corresponding letters or numbers stamped on the wood.



STEP-II

Fit mortise holes of the LEG ASSEMBLY onto the respective tenons of the TABLE TOP. If necessary, use rubber mallet to drive the tenons into place until all joints fit snugly together.



STEP-III





Secure LEG ASSEMBLY as shown in photographs using 1 Knock-Down Bolt and 2 Dowels. Use a wood block between the hammer head and the dowel head for the last few blows to avoid marring the wood.

NOTE

TABLE MUST BE UPRIGHTED BY TWO PEOPLE, ROLLING THE TABLE OVER MAY CAUSE STRUCTURAL DAMAGE TO ITEM. LEGS ARE NOT DESIGNED TO HANDLE THE PRESSURE OF ROLLING OVER THE TABLE. MUST LIFT OFF THE GROUND, ROTATE OVER AND SET DOWN RIGHT SIDE UP.







STEP-IV

To use EXTENSIONS, release the BUCKLES under the TABLE TOP, pull the edge of the TABLE TOP out like a drawer to reveal EXTENSIONS; roll them over into position and lock the EXTENSIONS into place.







BUCKLES

IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY BATE FURNITURE, PLEASE CONTACT KINGSLEY BATE CUSTOMER SERVICE AT 703-361-7000. WE THANK YOU FOR CHOOSING OUR FURNITURE.

* KINGSLEY BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY

> 7200 Gateway Court, Manassas, Virginia 20109 Phone: 703-361-7000, Fax: 703-361-7001