

KINGSLEY - BATE

Fine Garden Furniture

ASSEMBLY INSTRUCTION FOR THE NT - 10



SEAT SECTION




LEFT END FRAME



RIGHT END FRAME



BOTTOM STRETCHER



*** NOTE**

A TENON

B MORTISE HOLE

STEP-I

Unpack, inspect and lay the parts on a clean, flat, soft surface to avoid marring the wood.


NOTE: During assembly of furniture please match joints with the corresponding letter or numbers.



STEP-II

Fit the **BOTTOM STRETCHERS** and **SEAT SECTION** into the **LEFT END FRAME** mortises. If necessary, gently rock the leg assembly while pushing tenons into mortises until joints fit snugly. Fit the **RIGHT END FRAME**

mortises to the **BOTTOM STRETCHERS** and **SEAT SECTION**.



STEP-III

Insert all dowels as shown on assembly diagram.

IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY-BATE FURNITURE, PLEASE CONTACT THE KINGSLEY-BATE DEALER NEAREST TO YOU OR KINGSLEY-BATE DIRECTLY. WE THANK YOU FOR CHOOSING OUR FURNITURE.

** KINGSLEY-BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE
IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY*

7200 Gateway Court, Manassas, Virginia 20109
Phone. 703-361-7000, Fax. 703-361-7001