



# KINGSLEY-BATE

Fine Garden Furniture


## ASSEMBLY INSTRUCTIONS FOR THE SH-18



**CHAIR**



**ROCKERS**



### **STEP-I**

Place chair upside down on a clean, flat, soft surface to avoid marring the chair and carefully fit the ROCKERS onto the chair LEGS. Please note that there is a FRONT to the ROCKERS.



### **STEP-II**

Slide the split washers followed by the flat washer onto the KD (knock-down) BOLTS and loosely secure all KD BOLTS as shown in the photograph with the allen key provided. Once all

four KD BOLTS have caught on the threads you can then tighten completely down.

IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY-BATE FURNITURE, PLEASE CONTACT THE KINGSLEY-BATE DEALER NEAREST TO YOU OR KINGSLEY-BATE DIRECTLY. WE THANK YOU FOR CHOOSING OUR FURNITURE.

*\* KINGSLEY-BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE  
IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY*