


KINGSLEY-BATE

Fine Garden Furniture


ASSEMBLY INSTRUCTIONS FOR THE TB-35



RIGHT END FRAME



TABLE TOP



LEFT END FRAME



LEGS STRETCHER



HARDWARE

STEP-I




Unpack, inspect and lay the parts on a clean, flat, soft surface to avoid marring the wood.



STEP-II

Gently lay the TABLE TOP face down on a clean, flat, soft surface. Loosely attach RIGHT END FRAME to TABLE TOP as shown in the photographs (use short bolts to attach by hand. Do

not tighten all the way). Attach LEFT END FRAME same as above.



STEP-III

Carefully line up the LEG STRETCHERS to the END FRAME stretcher bar as shown in the photographs and insert

the long bolts from the outside of the frame. Secure all four bolts by hand as far as they will go.



STEP-IV

All knock down bolts can now be tightened by using the allen key provided. Carefully upright table.

IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY-BATE FURNITURE, PLEASE CONTACT THE KINGSLEY-BATE DEALER NEAREST TO YOUR OR KINGSLEY-BATE DIRECTLY. WE THANK YOU FOR CHOOSING OUR FURNITURE.

** KINGSLEY-BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY*