

KINGSLEY BATE™

ELEGANT OUTDOOR FURNITURE


ASSEMBLY INSTRUCTIONS FOR THE TR-114



LEG ASSEMBLY



TABLE TOP ASSEMBLY



DOWELS




LEG ASSEMBLY




BOTTOM LONG LEG STRETCHER

SHORT STRETCHER



LEG SUPPORT BRACKETS



*** NOTE**


A TENON

B MORTISE HOLE

STEP-I

Unpack, inspect and lay the parts on a clean, flat, soft surface to avoid marring the wood.



NOTE: During assembly of the furniture please match the tenons and mortise holes with the corresponding letters or numbers stamped on the furniture.



STEP-II




Making sure to carefully match the numbers / letters stamped on the component parts, fit **SHORT STRETCHER** tenons into the respective mortise holes of the

BOTTOM LONG LEG STRETCHERS and dowel assembly as shown.



STEP-III:

Again, (very important) carefully matching the numbers / letters stamped on the components, fit the **STRETCHER** assembly into the **LEG ASSEMBLY** frames as shown above.



STEP-IV:

Once you are certain that the LEGS line up with the apron under the TABLE TOP ASSEMBLY, Insert all dowels as shown in the photographs. Use

the wood block provided in between the hammer head and dowel head for the last few blows to avoid marring the wood.



STEP-V

Fit the BASE ASSEMBLY onto the TABLE TOP ASSEMBLY and matching the numbers / letters stamped on the legs to the numbers / letters shown on the TABLE TOP ASSEMBLY dowel as shown. Use the wood block provided in between the hammer head and dowel head for the last few blows to avoid marring the wood.



STEP-VI

Fit the LEG SUPPORT BRACKETS to the LEGS and APRON as shown and secure with a proper hand held screw driver. Use of power tools could easily strip the wood. **IMPORTANT:** Two people are required to upright this table, **DO NOT ROLL TABLE OVER**, legs are **NOT** designed to support the weight at that angle. To upright, lift table from one side without letting weight rest on legs. Then lift off the ground, rotate to upright position and set table evenly on the ground.

IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY BATE FURNITURE, PLEASE CONTACT KINGSLEY BATE CUSTOMER SERVICE AT 703-361-7000. WE THANK YOU FOR CHOOSING OUR FURNITURE.

**** KINGSLEY BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY***