KINGSLEY~BATE

Fine Garden Furniture
ASSEMBLY INSTRUCTIONS FOR THE WS-59








LEG ASSEMBLY

BOTTOM STRETCHER

TABLE TOP





NOTE: A TENON B MORTISE HOLE STEP-I

Unpack, inspect and lay the parts on a clean, flat, soft surface to avoid marring the wood.

NOTE: During assembly of the furniture please match all joints with the corresponding letters or numbers stamped on the furniture. This is a two person project.







STEP-II

With the table top upside down on a clean, smooth surface, fit one LEG ASSEMBLY

mortise holes onto the TABLE TOP tenons as shown in the photographs. If necessary, gently rock the LEG ASSEMBLY while pushing tenons into the mortise holes until joints fit snugly (use of a rubber mallet may be needed). Again, matching the numbers stamped on the tenons with the mortise holes, fit the BOTTOM STRETCHER as shown in the photograph (please note there is a top and bottom side to the BOTTOM STRETCHER). While holding BOTTOM STRETCHER in place, fit the second LEG ASSEMBLY, as shown in photographs. If you need to use a rubber mallet to drive the joints together you should have one person on either side of the table; one to keep the parts from sliding on your smooth surface or shifting left to right, the other to drive the joints.







STEP-III

Carefully hammer the dowels into the pre-drilled holes of the assembly and secure the screws with a proper hand held screwdriver to the underside

apron of the LEG ASSEMBLIES, details are shown in the photographs.

NOTE: DO NOT FORCE THE DOWELS; ANY EXCESS CAN EASILY BE SANDED AWAY. IF THE DOWELS ARE NOT FLUSH DO NOT CONTINUE TO DRIVE THE DOWELS, YOU MIGHT DAMAGE THE ITEM. USE OF A POWER SCREWDRIVER IS <u>NOT</u> RECOMMENDED. THE TORQUE OF A POWER SCREWDRIVER CAN EASILY STRIP THE SCREW HOLE.

NOTE: TO UPRIGHT THE TABLE LIFT STRAIGHT UP, ROTATE IN THE AIR AND SET IT BACK DOWN. ROLLING THE TABLE OVER MAY CAUSE DAMAGE TO THE ITEM.



IF YOU HAVE ANY QUESTIONS REGARDING THE ASSEMBLY OF YOUR KINGSLEY-BATE FURNITURE, PLEASE CONTACT THE KINGSLEY-BATE DEALER NEAREST TO YOU OR KINGSLEY-BATE DIRECTLY. WE THANK YOU FOR CHOOSING OUR FURNITURE.

*KINGSLEY-BATE WILL NOT TAKE RESPONSIBILITY FOR DAMAGE IF THESE INSTRUCTIONS ARE NOT FOLLOWED PROPERLY.